

# SPRING BALANCER


*Spring Balancer Improves Work Safety & Efficiency.  
Capacities ranging from 0.5~70kg.*



MODEL	Capacity (kg)	Stroke (m)	Weight (kg)
TW-00	0.5~1.5	0.5	0.2
TW-0	0.5~1.5	1.0	0.5
TW-3	1.0~3.0	1.3	1.4
TW-5	2.5~5.0	1.3	1.5
TW-9	4.5~9.0	1.3	3.4
TW-15	9.0~15.0	1.3	3.8
TW-22	15.0~22.0	1.5	7.2
TW-30	22.0~30.0	1.5	7.6
TW-40	30.0~40.0	1.5	9.8
TW-50	40.0~50.0	1.5	10.4
TW-60	50.0~60.0	1.5	11.6
TW-70	60.0~70.0	1.5	11.8



# HOSE REEL BALANCER SERIES



MODEL	Capacity (kg)	Stroke (m)	Weight (kg)	Hose DIA (Ø mm)
HW-0	0.5~1.5	1.3	1.6	Ø6.5 / Ø10
HW-3	1.5~3.0	1.3	1.7	Ø6.5 / Ø10
HW-5	3.0~5.0	1.3	1.8	Ø6.5 / Ø10

-Functions both as balancer and hose reel

# RETRACTOR SERIES



MODEL	Capacity (kg)	Stroke (m)	Weight (kg)
RW-0	0.5~1.5	2.0	0.5
RW-3	1.0~3.0	2.0	0.7
RW-5	2.5~5.0	2.0	0.9

-Tension easily adjustable using knob

MODEL	Capacity (kg)	Stroke (m)	Weight (kg)
TW-1R	0.5~1.5	1.5	0.3

-Tension easily adjustable using knob

**NITTO KOHKI CO., LTD.**

Web [www.nitto-kohki.co.jp/e/](http://www.nitto-kohki.co.jp/e/)

**Head Office**

2-9-4, Nakaikegami, Ota-ku, Tokyo 146-8555, Japan  
 Tel : +81-3-3755-1111 Fax : +81-3-3753-8791  
 E-mail : [overseas@nitto-kohki.co.jp](mailto:overseas@nitto-kohki.co.jp)



DISTRIBUTED BY